

Setting up and using Voicemail

Logging into your voicemail box:

Press **Open Mailbox**, enter your password followed by **#** and follow the prompts.

To access voicemail remotely:

From another phone on your system, Press **Open Mailbox** **OR**
 From outside your system, call a phone number connected to your system.
 When your voicemail system picks up enter **# 6 *** and your mailbox number
 Then enter your password followed by **#**.
 You are now in your mailbox. Follow the mailbox prompts.

Access your mailbox administration

(this allows you to change your greetings, Password, Name, etc)

Login to your mailbox (see above)

Press **3** to enter Mailbox Management

Next step:

Press **1** to change Personal Greetings (this is the message that the caller hears when they reach your mailbox)

Press **2** to change your Password

Press **3** to change your Name for the directory

Follow the prompts after each selection to ensure that you save the new info that you enter.

NOTE: It is always best to lift your handset and speak clearly into the handset when recording greeting.

How to set up message notification:

Login to your voicemail box. (see above)

Press **5** to set up messaging waiting notification.

Press **3** to add or change the phone or pager number to be notified for message waiting.
 (Be sure to enter the line access code (generally "9") in front of the phone number)

Follow prompts.

Panasonic User Sheet

(KX- DT Series Phones)

not all soft/fixed keys available on DT321

DISPLAY FEATURES: (4 "soft" keys)

PROG	Used to program keys	RING	Volume of the Ring Tone
INFO	Date/Time/Day of Week Extension /Name or Day/Night Mode	MENU	Personal/System/ Extension Directories, Incoming/ Outgoing Call Logs, Feature Access Programming

4-WAY NAVIGATION KEY:

Up/Down	Adjust volume while on a call (both handset & speaker) Change the volume of your ringer.
Left/Right	Call Logs, Personal/System/Extension Directories, Feature Access

12 FIXED KEYS:

CONF	Conference calls together (maximum of 8 parties)
FWD/DND	Forward your phone to an external number or to another extension. Do Not Disturb can be set for internal calls, external calls or both.
PAUSE	Used for programming or to insert a pause when storing numbers.
INTERCOM	Internal calls. Press Intercom button + Extension number or 1-touch
AUTO ANS/MUTE	Auto Answer: If engaged it will answer intercom calls hands free Mute: Used to mute the microphone of your speaker or your handset during a phone call
AUTO DIAL/STORE	Used for System and Personal speed dialing or for storing program changes

PAGE 2

MESSAGE Used to leave a message waiting indication lamp or call back the person that left you a message internally. Message waiting is indicated by a solid red light on the top right corner of your phone.

REDIAL Redial the last number called

TRANSFER Used to transfer a call to another internal extension

FLASH/RECALL Used to disconnect the current call and make another without hanging up. Also used as a CANCEL button while on-hook.

HOLD Used to place a call on hold

SP-PHONE Used for hands free operations

Ring Tones: (30 to choose from)

To Program:

Press **PROG**

Press the **Line** or **INTERCOM** 2 times

Use up and down arrows on navigation key to listen to the tones

Press **AUTO DIAL/STORE** to store the ring

To Make an External Call:

Press an available line access button or dial the line access code (generally “9”), then dial the desired telephone number

To Make an Internal Call:

Lift handset or Press **SP-PHONE**. Dial the desired extension number or press the one touch button.

To Park a Call:

With the caller on the line press **TRANSFER**, Call Park key (or *52) + the 2-digit zone in which to park the call (00-99) or hit * for the system to assign an idle zone.

To retrieve Parked Call:

Press the Call Park feature key (or *52) + the 2-digit parking zone.

To Transfer a Call:

With the caller on the line press **TRANSFER**, then dial the extension you need or press the one touch extension button. Announce the call (optional) and hang up.

PAGE 3

To Place a Call on Hold:

With the caller on the line press **HOLD**. The active outside line button flashes green.

To retrieve a call on hold:

A call that is holding on your extension will flash green. A call holding on another extension will flash red. Select the line that you would like to pick up. Lamp will turn solid green.

To make a conference call:

While on a call, press **CONF**, make 2nd call, press **CONF**, etc

Personal Speed Dial (00-09)

To Program: Lift handset. Press ***** **3** **0**, then enter the desired 2-digit code (00-09), enter the line access code (generally “9”) followed by the telephone number, then **#**

To Use: Lift handset. Press **AUTO DIAL/STORE** ***** plus the 2-digit code (00-09).

Programming your phone for One Touch Dialing:

STEP 1:

Press **PROG** (soft key)

Press the One Touch button that you would like to program

Press **CLEAR** (soft key) or **FLASH/RECALL** to erase any previous programming

STEP 2:

To Program a Speed Dial Number:

Dial the Line Access Code (generally “9”) followed by the phone number
OR

To Program a Feature Button:

Press the feature code (if you do not know the code then simply press the Up/Down on the navigation wheel to scroll through the feature codes).
OR

To Program an Extension:

Dial 3 digit extension number that you want stored

STEP 3:

Press **AUTO DIAL/STORE**

Note: repeat these steps for each button that you would like to program